

## ASSEMBLY INSTRUCTIONS **MODEL: 2118**


T T C R Z - S H - Z G S PERFORMANCE


Before assembly, please remove all parts from the carton, verifying that you have the correct quantities, and read all the instructions.


Allen Wrench SMM		1	ಕ
Ф13xФ8xT2.5mm	0	3	15
	Q	2	14
	0	2	13
Ф20xФ8.5xT1.5mm	0	5	12
Ф15xФ7.5xТ12mm	8	4	11
M8x25mm	9	2	10
M8x25mm		3	9
M6x35mm	9	4	8
Armrests	D	2	7
Mechanism		1	6
Chair back		1	5
Seat Cushion	0	1	4
Gas lift	Q	-	ω
Chair base	7	1	2
Casters	₿	5	1
DESCRIPTION		ary	KEY
		JST	PART LIST











## CARE & MAINTENANCE

GENERAL CARE parts wipe the surface with a clean cloth To maintain the appearance of non-uphoistered

dampened with a mild detergent solution.
Do not remove any parts for separate cleaning.
Do not saturate the fabric or interior with water or other cleaning liquids

Do not clean with hot water extraction machine. Do not clean with onsite dry cleaning machine. Protect from direct sunlight, heat and weather.

Do not shampoo clean.

Wipe with a clean cloth dampened with a mild uphoistery detergent solution. UPHOLSTERY CARE

A soft bristle brush may be used to remove

Use only leather care products suitable for top coated leather and strictly in accordance with the manufacturer's instructions.

Spot clean as above. Treat spills and stains as soon as possible. orolessional cleaner. Persistent stains may require treatment by a lilow to dry thoroughly before reuse

Dispose of packaging properly.

Plastic bag is not a toy. · Failure to follow these warnings could result in serious injury. Do not use plastic bag as a head covering as it may cause

## PREVENTATIVE MAINTENANCE & WARNING!

- Use this product only for seating one person at a time.
  Do not use this chair as a step stoot/ladder
  Do not use this chair on the chair except the seat.
  Do not use this chair on uneven floor surfaces.
  Do not interfere with the operating of the gas lift.
  Do not use chair unless all boits, screws and knobs are tight.
- At least every six months check all boits, screws and knobs to
- if any parts are missing, broken, damaged or worn do not use the product until repairs are made using factory authorized parts.

TI NOLINELLY I

If any parts are missing, broken, damaged or worn, stop use of product until repairs have been made using factory authorized parts. Ensure all bolts and screws are tightened before using the chair, check bolts and screws every 6 months. Do not tighten any screws or bolts until the unit is completely assembled.

Failure to follow these warnings may result in injury.